

# **CFD Modeling of Pleated Filter Elements with the Experimental Validation using PIV**

**Seungkoo Kang, David Y. H. Pui, and Jacob Swanson**

*Particle Technology Laboratory  
University of Minnesota*

CFR 51<sup>st</sup> Review Meeting, Mechanical Engineering  
University of Minnesota  
May 5<sup>th</sup>, 2017




**Center for Filtration Research**



**UNIVERSITY OF MINNESOTA**


Accurately modeling filtration performance requires  
resolving microstructures of pleated filters

→ tremendous computational resources and time




# PIV Particle image velocimetry

- Measure **fluid** velocity vectors at many points in a flow field simultaneously
- From mm/s to supersonic velocity



Raffel et al. Particle Image Velocimetry (2007)

# PIV Particle image velocimetry




an optical imaging technique to measure fluid or particle velocity vectors at many points in a flow field simultaneously




# Application example of PIV measurement

PIV technique is applied to a wide range of possible applications:

Gas turbine combustor, Automotive, Aerospace, Propulsor hydrodynamics, Biomedical devices, Electronics, Airplanes, Helicopters, ...




Experimental setup of the  
**propelled ship model**



Velocity map of near-propeller wake

# Application example of PIV measurement


## Diffuser purging concept






**Diffuser** to purge out humid air using laminar flow.

## Diffuser flow measurement using PIV


Double pulse laser



Mass flowmeter  
CDA  
Atomizer



# Objectives



Flow apparatus



Vertical orientation



Horizontal orientation

- Measure **flow profiles** up/downstream: PIV system
- To conduct a **CFD simulation**  
Find a proper model for the effective CFD modeling of pleated filter
- To compare **pressure drop** and **velocity profiles** between the experiment and simulation



# **Last CFR meeting**

- **Preliminary data collection**
- **CFD mesh independence study**





## **This presentation**


- **Velocity distribution comparison**
- **Pressure drop comparison**




# Filter orientation



**0 Degree**




**30 Degree**





**45 Degree**

# Experimental setup



# PIV setup



# Experimental condition

Inclined angles	0				30				45			
Filter orientation	Horizontal		Vertical		Horizontal		Vertical		Horizontal		Vertical	
Flow rates	21	43	80	107	21	43	80	107	21	43	80	107
Measured plane	Plane1		Plane2		Plane1		Plane2		Plane1		Plane2	

0 degree



30 degree




45 degree



Vertical



Horizontal






plane1

plane2




# CFD modeling of pleated filter



- For computational fluid dynamics (CFD) modeling,  
Pleated filter media  Porous domain
- Experimental pressure and velocity data  
 porous coefficients

# Porous coefficient derivation




Porous coefficients ( $\alpha$ ,  $C_2$ ) can be obtained experimentally

$$\Delta P = \frac{C_2 \rho \Delta n}{2} v^2 + \frac{\mu}{\alpha} \Delta n v,$$

$C_2$  = *Inertial* resistance factor,  $\frac{1}{\alpha}$  = *viscous* resistance factor

$\alpha$  = permeability,  $\Delta n$  = filter thickness


# Porous coefficient determination



**Applying proper x, y, z tensor values is important for modeling pleated filter media**

# CFD simulation

- **Fluent version: 16**
- **Physics model: k- $\omega$  SST**
- **Boundary conditions**





# Pressure drop


Inclined angle (degree)	Volumetric flow rate (CFM)	$\Delta p$		Error %
		Experiment (Pa)	CFD (Pa)	
0	21	26	25	3%
	43	55	53	3%
	80	109	108	1%
	107	154	152	2%
30	21	25	25	0%
	43	53.5	52	2%
	80	107	107	0%
	107	150	149	0%
45	21	25	26	2%
	43	55	54	2%
	80	108	110	2%
	107	154	156	1%

**CFD data is in good agreement with experimental data**


# 0 degree contour plot (21CFM)




**Vertical arrangement**




**Horizontal arrangement**



# Velocity distribution comparison







Velocity  $u$  (m/s) vs  $Y$  (mm)



Velocity will be compared between CFD and PIV data after filter





# Velocity distribution comparison (5cm)



**Experimental data is averaged over 100 flow profiles**




# Velocity distribution comparison (15cm)




# 30 degree\_107CFM\_plane2


CFD simulation



PIV experiment








Vertical arrangement



Horizontal arrangement




# 30degree

## Horizontal vs Vertical arrangement




# Velocity distribution comparison (15cm)

	Fluent_1	Fluent_2	Fluent_3
Coeff. in x	$\alpha_x, C_{2,x}$	$\alpha_x, C_{2,x}$	$\alpha_x, C_{2,x}$
Coeff. in y	0	$0.5*\alpha_x, 0.5*C_{2,x}$	$100*\alpha_x, 100*C_{2,x}$
Coeff. in z	0	$100*\alpha_x, 100*C_{2,x}$	$0.5*\alpha_x, 0.5*C_{2,x}$






# Velocity distribution comparison (15cm)




# 45 degree\_107CFM\_plane2


CFD simulation



PIV experiment








Vertical arrangement



Horizontal arrangement




# 45degree

## Horizontal vs Vertical arrangement




# Velocity distribution comparison (15cm)

	Fluent_1	Fluent_2	Fluent_3
Coeff. in x	$\alpha_x, C_{2,x}$	$\alpha_x, C_{2,x}$	$\alpha_x, C_{2,x}$
Coeff. in y	0	$0.5*\alpha_x, 0.5*C_{2,x}$	$100*\alpha_x, 100*C_{2,x}$
Coeff. in z	0	$100*\alpha_x, 100*C_{2,x}$	$0.5*\alpha_x, 0.5*C_{2,x}$





# Velocity distribution comparison (15cm)



# Summary

- **CFD and PIV experimental results were compared**
- **0 and 30 degree CFD models agree well with PIV experimental data**

## Future works

- **Verify the behavior of the flow with different pleated filter media**

# Thank you



Center for Filtration Research



UNIVERSITY OF MINNESOTA