

Field Measurement of Nanoparticle Surface Area using the Geometric Surface Area Monitor by the Weighted Sum Method

Leo Cao and David Y.H. Pui




Outline

- ☐ Background and objective
- ☐ Methodology
- ☐ Experiments
- ☐ Summary



Significance of surface area



- Catalytic activity
- Drug delivery
- Particle reactivity
- Health effect


1 → **10,000,000x**
surface area



Health effect

Percent of Neutrophils in BAL 24 hrs after Instillation of TiO_2 in Rats

Correlation with Particle Surface Area



Oberdörster, G. (2000). Pulmonary effects of inhaled ultrafine particles. *International archives of occupational and environmental health*, 74(1), 1-8.




Methods for surface area: offline



BET method (gas adsorption):

- Surface area including pores
- Direct (standard)
- Ex situ
- Time consuming
- Costly




Electron microscopy (TEM and SEM):

- 2D projected area
- Ex situ
- Time consuming
- Costly





Methods for surface area: online




Scanning Mobility Particle Sizer (SMPS) Spectrometer:

- Mobility diameter based distribution
- Minutes
- Bulky
- Working fluid
- Radiation source
- Costly



Fast Mobility Particle Sizer (FMPS) Spectrometer:

- Mobility diameter based distribution
- 1 s resolution
- Bulky
- Data inversion
- Costly





Methods for surface area: online 2



Nanoparticle Surface Area Monitor (NSAM):

- Mobility diameter based
- 1 s resolution
- Reasonable size and cost for field measurement
- Only lung-deposited surface area



So far, none quick and easy way to measure the geometric surface area (GSA) of particles



Objective

A cost effective method delivering geometric surface area (**GSA**) concentration of nanoparticles in real time.

Features:

- Real time, GSA
- Transportation friendly: no working fluid, no radiation source, light-weight, and field portable.



Outline

☐ Background and objective

☒ Methodology

☐ Experiments

☐ Summary



Methodology

- Using Nanoparticle Surface Area Monitor (NSAM) as the basic tool





- Linearly combining the signal (under different condition) to fit GSA (geometric surface area) measurement.



Appendix 1

NSAM (Nanoparticle Surface Area Monitor)





Changing voltage of ion trap



Combining electrical current under different voltages



Average charge of particle \propto surface area



Geometric Surface Area Monitor (GSAM): block-shaped voltage pulse



LabVIEW-controlled voltage pulse makes the continuous sampling.



Outline

☐ Background and objective


☐ Methodology

☒ Experiments

☐ Summary



1. Validation in lab






- The neutralized **polydisperse** aerosols were measured by GSAM and SMPS in parallel.
- Geometric surface area concentrations were compared to test the accuracy of the GSAM.




Appendix 2 for calibration

Test aerosol from atomizer

1. KCl, SiO₂, Au(gold), PSL(Polystyrene Latex), DEHS(Di-Ethyl-Hexyl-Sebacat).
2. Surface area distribution: 20-300 nm, range of accurate measurement
3. Surface area distribution: >300 nm, outside accurate range
4. Multi-modal distribution



SMPS vs. GSAM (spheres)




GSAM works great for 20-300 nm; works fine for >300 nm.




SMPS vs. GSAM (agglomerates)



Data for SMPS are using **agglomerate correction** with primary particle size: 13.8, 16.2, 19.5 *nm* with (Wang et al., 2010; Kim et al., 2009; Shin et al., 2010.)




Calibration curve for spheres works fine for agglomerates.



2. Field measurement

- Parallel sampling using GSAM and SMPS
 - SMPS: one sample every 62 s (17.5-532.8 nm)
 - GSAM: one average value for every 50 s. 12 s for sampling and 38 s for stabilizing voltage





- Location or event: lab 4130, outdoor, laser printing, grinding, waterjet cutting, welding






Lab ME

Sampling length: ~5 hours



- At very low concentration, the GSA from GSAM and SMPS agree well with each other including the emission event.
- GSAM is more stable.






	GSAM	SMPS (CPC)
Detection limit (DL)	1 fA	1 #/cm ³
Lowest signal here	4.8 fA (4.8 times of DL) ✓	1#/cm ³ (1 time of DL)



Outdoor

Sampling length: ~6 hours




The trend and concentration were both well captured by GSAM for outdoor aerosol.



Laser printer in computer lab

Sampling length: ~1 hour




- For wide variation of GSA concentrations, GSAM is accurate.
- Large error bars are due to transient emission.



Machine shop

Sampling length: ~4.5 hours




- The trends agree with each other.
- Transient emission are difficult for both instruments.



Correlation between GSAM and SMPS

GSAM



- Overall, both measurements agree well with each other.
- Discrepancy comes from the particle shape and transient emission.



Outline

☐ Background and objective

☐ Methodology

☐ Experiments


☒ Summary



Summary

The novel GSAM successfully measures the GSA of both lab-generated and real environment particles with the following features:

- In a wide range: 20 to 530 nm
- Possibly time resolution can be within several seconds
- For the mixture of spheres and agglomerates
- For both indoor and outdoor
- Cost-effective and field-portable
- With simple setup



Thank you



Major reference

- Kaminski, H., Kuhlbusch, T. A. J., Fissan, H., Ravi, L., Horn, H.-G., Han, H.-S., . . . Asbach, C. (2012). Mathematical Description of Experimentally Determined Charge Distributions of a Unipolar Diffusion Charger. *Aerosol Science and Technology*, 46(6), 708-716. doi: 10.1080/02786826.2012.659360
- Lall, A. A., & Friedlander, S. K. (2006). On-line measurement of ultrafine aggregate surface area and volume distributions by electrical mobility analysis: 1. Theoretical analysis. *Journal of Aerosol Science*, 37(3), 260-271. doi: 10.1016/j.jaerosci.2005.05.021
- Li, L., Chen, D.R., & Tsai, P.J. (2009). Use of an electrical aerosol detector (EAD) for nanoparticle size distribution measurement. *Journal of Nanoparticle Research*, 11(1), 111-120. doi: 10.1007/s11051-008-9418-8
- Sorensen, C. M. (2011). The Mobility of Fractal Aggregates: A Review. *Aerosol Science and Technology*, 45(7), 765-779. doi: 10.1080/02786826.2011.560909
- Vosburgh, D. J. H., Ku, B. K., & Peters, T. M. (2014). Evaluation of a Diffusion Charger for Measuring Aerosols in a Workplace. *Annals of Occupational*
- Wei, J.M., Kruis, F.E., & Fissan, H. (2007). A method for measuring surface area concentration of ultrafine particles. *European Aerosol Conference 2007*. Abstract retrieved from abstracts in European Aerosol Conference database. (Accession No. T02A043)



Appendix 1.1 Current, sensitivity, and GSA

$$S(d, v_1, v_2, a) = S(d, v_1) + aS(d, v_2) \quad (1)$$

$$\text{If } S(d, v_1, v_2, a) = k\pi d^2 \quad (2)$$

where k is a constant that can be determined in the instrument calibration.

The total current measured by the electrometer for polydisperse aerosol can be expressed as:

$$\begin{aligned} I &= I(v_1) + aI(v_2) \\ &= \int_{d=0}^{+\infty} S(d, v_1) \frac{dN(d)}{d \log d} d \log d + \int_{d=0}^{+\infty} aS(d, v_2) \frac{dN(d)}{d \log d} d \log d \\ &= \int_{d=0}^{+\infty} [S(d, v_1) + aS(d, v_2)] \frac{dN(d)}{d \log d} d \log d \\ &= \int_{d=0}^{+\infty} S(d, v_1, v_2, a) dN(d). \end{aligned} \quad (3)$$

where $I(v)$ is the total current measured by the electrometer.

Substituting Eq. 2 into Eq. 3,


$$I = k \int_{d=0}^{+\infty} \pi d^2 dN(d) \quad (4)$$

where $\int_{d=0}^{+\infty} \pi d^2 dN(d)$ is the total GSA concentration, A_g , in $\mu\text{m}^2/\text{cm}^3$ for the polydisperse aerosol, then

$$A_g = \frac{I}{k}. \quad (5)$$



Appendix 1.2 Sensitivity fitting




Appendix 2.1 Sensitivity of the monitor:

electrical current, fA


$$S = \frac{\text{electrical current, fA}}{\text{number concentration, \#/cm}^3}$$




KCl from
21 to 487 nm



Silver agglomerates
from 40 to 300 nm



Appendix 2.2 Sensitivity at different voltages




Appendix 3. GSA for agglomerates

Instead of $S(d) \propto d^2$, we need $S(d) \propto \text{GSA}$ for agglomerates

**GSA of one agglomerate
by Sorensen, 2001:**

$$\begin{aligned}\pi N_{pp} d_{pp}^2 &= \pi d_{pp}^{-0.17} d_m^{2.17}, N_{pp} < 100, \\ \pi N_{pp} d_{pp}^2 &= 2.16 \pi d_{pp}^{0.21} d_m^{1.79}, N_{pp} > 100\end{aligned}$$



**GSA of one agglomerate
by Lall & Friedlander, 2006:**

$$\pi N_{pp} d_{pp}^2 = \frac{12\pi^2 \lambda d_m}{c^* C_c(d_m)}$$

Where N_{pp} is the number of primary particle, d_{pp} is the diameter of the primary particle, d_m is the mobility diameter, C_c is the slip correction, c^* is the dimensionless drag force and λ is the mean free path of the gas.

