

# Non-IPA Production of DEHS Nanoparticles for Evaluating PTFE Filter

Min Tang<sup>1</sup>, Sheng-Chieh Chen<sup>1</sup>, Wilson Poon<sup>2</sup>, and  
David Y.H. Pui<sup>1</sup>

<sup>1</sup>*University of Minnesota*

<sup>2</sup>*W. L. Gore & Associates, Inc*

*May 5, 2017*

*51<sup>st</sup> Review Meeting, Minneapolis MN*



Center for Filtration Research



UNIVERSITY OF MINNESOTA

# Content

- Introduction
- Methods to reduce particle size
- Neutralization of DEHS particles
- Conclusion



# Content

- Introduction
- Methods to reduce particle size
- Neutralization of DEHS particles
- Conclusion



# Introduction

- ❖ Polytetrafluoroethylene (PTFE) membrane filtration media, which exhibit high efficiency and low pressure drop, have been widely used in air filtration products. (Galka and Saxena 2009)
- ❖ For PTFE membrane and other nanofiber filters, the Most Penetration Particle Size (MPPS) is typically between 0.07 to 0.1 micron.
- ❖ According to EN 1822-5-2009, when using a polydisperse aerosol to test filter element, it's required that the median diameter  $D_M$  should be +/-50% of MPPS.

*Galka N, Saxena A. High efficiency air filtration: The growing impact of membranes. Filtration & Separation. 2009 Aug 31;46(4):22-5.*

*EN 1822-5-2009, High efficiency air filters (EPA, HEPA and ULPA). Determining the efficiency of filter elements.*





# Introduction

- ❖ In EN 1822, possible aerosol substances include: DEHS, PAO and Paraffin oil.
- ❖ To achieve smaller particle sizes, one method is to dilute the DEHS using highly volatile solvent, e.g. Isopropyl Alcohol (IPA).
- ❖ Issues of using IPA:
  - Particles may get highly charged
  - Stability of particle size distribution
  - Flammability
  - IPA intoxication (Zaman, et al. 2002)

*Zaman F, Pervez A, Abreo K. Isopropyl alcohol intoxication: a diagnostic challenge. American Journal of Kidney Diseases. 2002 Sep 30;40(3):e12-1.*



# Objective

## Goal:

- ❖ Generate particles with count median diameter (CMD) of 70-100 nm using 100% DEHS.
- ❖ Particle concentration is high enough to provide statistically meaningful results for high efficiency filters such as E12 or higher.




# Content

- Introduction
- Methods to reduce particle size
- Neutralization of DEHS particles
- Conclusion




# Six-jet atomizer (TSI 9306)



- ☐ 1 jet on
- ☐ 100% DEHS
- ☐ Compressed air: 80 psi, 14 L/min




# Particle size distribution of original atomizer



	Count Media Diameter (CMD), nm	< 100 nm Total number Concentration, $10^8 \text{ \#}/\text{cm}^3$
Original	$160.6 \pm 0.4$	0.289




# Methods to reduce particle size



## Method 1


- ❑ Smaller nozzle



## Photo Chemical Etched Mesh


- Pore size: 150 µm

# Effect of mesh on CMD and particle concentration




	Count Media Diameter (CMD), nm	< 100 nm Total number Concentration, $10^8 \text{ \#/cm}^3$
Original	$160.6 \pm 0.4$	$0.289 \pm 0.003$
Original + Mesh	$151.1 \pm 0.4$	$0.329 \pm 0.012$

# Methods to reduce particle size



## Method 2

- ❑ Quick dilution to reduce coagulation





Quick dilution tube



# Effect of dilution flow rate on CMD and particle concentration

- With mesh



- Higher dilution flow rate leads to smaller Count Median Diameter (CMD) and higher <100 nm particle concentration.




# Content

- Introduction
- Methods to reduce particle size
- Neutralization of DEHS particles
- Conclusion



# Experimental method

## Percentage of charged particles in polydisperse particle



$C_{\text{total}}$ : particle number concentration measured by CPC when ESP is **OFF**.

$C_{\text{neutral}}$ : particle number concentration measured by CPC when ESP is **ON**.

$$\text{Percentage of charged particles} = 1 - C_{\text{neutral}}/C_{\text{total}}$$

# Percentage of charged particles in polydisperse DEHS particle

- 100% DEHS

	Percentage of charged particles	Std
No neutralization	2.4%	0.6%


Most of particles generated by pure DEHS are neutral.



# Home-made neutralizer




4 x Po-210 Strips



# Result and discussion

## Effectiveness of home-made neutralizer



# Content

- Introduction
- Methods to reduce particle size
- Neutralization of DEHS particles
- Conclusion



# Conclusion

- ❖ Mesh and quick dilution were applied to atomizer, which reduce count median diameter (CMD) of 100% DEHS from 160 nm to 100 nm.
- ❖ Higher dilution flow rate leads to higher <100 nm particle concentration.
- ❖ Most of particles generated by pure DEHS are neutral.

## Future work

- ❖ Optimize the design to further reduce CMD.
- ❖ Neutralization evaluation for high flow rate atomizer.

