

Liquid Filtration: Effects of Chemical and Physical Factors on Filtration Performance for Micro- and Ultrafiltration Membranes

Handol Lee and David Y. H. Pui

**Center for Filtration Research (CFR)
Mechanical Engineering
University of Minnesota**

INTRODUCTION

- **Micro-** (100 nm ~ 1 μ m) and **ultra-filtration** (10 nm ~ 100 nm) using membranes have been widely used and considered an effective technique to separate suspended particles from liquid in many industries.
- Retention mechanisms of colloidal particles are **adsorption** (PPD* < 1, small particle) and **size exclusion** (PPD* > 1, large particle), depending on particle and pore size.
- The performance (efficiency) of liquid filtration is hard to predict due to **complex interactions** between solid surfaces in liquid.
- Pore size alone cannot explain filter performance well.
- Both theoretical and experimental studies are important.

Modeling

- Interaction energy

Experiment

- Concentration measurement method
- Polydisperse particle filtration

***PPD: Particle to pore diameter ratio**

OUTLINE

- **Modeling**

- **Two different membrane filters (PCTE* and PP*)**
- **Different chemical (ionic strength) and physical (filtration velocity) conditions**
- **Interaction energy between particle and filter**

- **Experiment**

- **Different characterization methods for measuring liquid-borne particle concentration (NTA* and ES-SMPS*)**
- **Polydisperse particle filtration (PES*)**

*PCTE: Polycarbonate track-etched (Nuclepore filter)

*PP: Polypropylene

*PES: Polyethersulfone


*NTA: Nanoparticle tracking analysis

*ES-SMPS: Electrospray-scanning mobility particle sizer


Polycarbonate track-etched (PCTE) and Polypropylene (PP) Filter Modeling

Filter and Particle System

PCTE (straight-through pore)



PP (fiber)




- Two membranes with **straight-through pores** (PCTE*) and **fibers** (PP*) are modeled.
- Particles smaller than absolute pore sizes are used to consider adsorption (sieving is excluded).
- **Surface interactions** between particle and filter in different chemical (ionic strength) and physical (filtration velocity) conditions are considered.

*PCTE: Polycarbonate track-etched membrane (Nuclepore filter)

*PP: Polypropylene membrane

Deposition Process (3 Steps)




- **Particles are captured by membrane through 3 steps.**

- 1) TRANSPORT:** Contact efficiency (air and liquid filtration)
- 2) ADHESION:** Interaction energy (liquid filtration)
- 3) TORQUE:** Detachment (liquid filtration)



Particle Transport (PCTE)

Transport

← **Number of particles colliding with filter surface**



PCTE (straight-through pore)



- **4 deposition mechanisms are considered for PCTE membrane.**

- 1) Impaction** on filter surface
- 2) Interception** on pore opening
- 3) Diffusion** on filter surface
- 4) Diffusion** on pore walls




**To get transport efficiency ...
Aerosol filtration theory
Capillary tube model
(Air to liquid)**




*H. Lee, D. Segets, S. Süß, W. Peukert, S. Chen, D.Y.H. Pui, J. Memb. Sci. 524 (2017) 682–690.

Particle Transport (PP)

Transport



PP (fiber)





**Polydisperse
fibers (2D)**

- Calculation domain with polydisperse fibers is generated based on **SEM image (fiber diameter)** and **filter information (solidity)**.
- Ansys Fluent software is used for flow and particle simulation.

Particle Adhesion (DLVO Theory)

Adhesion



- Solution chemistry
- Particle/filter material
- Particle size
- Separation distance

Attachment ratio

$$= \frac{\text{\# of attached particles}}{\text{\# of colliding particles}}$$

Obtained from **TRANSPORT**

DLVO theory* describes the force between charged surfaces interacting through a liquid medium.


- From total interaction energy curve, successful **attachment ratio** (successful adhesion) and corresponding **adhesion energy** can be obtained.
- Attachment energy (attraction) is used for calculating adhesion torque.

***DLVO: Derjaguin-Landau-Verwey-Overbeek**


*H. Lee, D. Segets, S. Süß, W. Peukert, S. Chen, D.Y.H. Pui, J. Memb. Sci. 524 (2017) 682-690.

Adhesion and Hydrodynamic Torque

Torque




Adhesion torque is not a function of adhesion location, but hydrodynamic torque is a function of it due to flow velocity difference.



- **Adhesion torque** is obtained from total DLVO interaction curve, and **hydrodynamic torque** can be accessed by flow simulation.
- Away from stagnation points, higher hydrodynamic force acts on particles.
 - Easily detached from surface

Particle Tracking Analysis Using UDF


- **User defined function (UDF*)** is incorporated in **Ansys Fluent** for particle tracking.
- **All three steps are imbedded in UDF for all individual particles.**





***UDF: User defined function**

Filtration Efficiency (PCTE and PP)

PCTE (Straight-through)





PP (Fiber)




*H. Lee, D. Segets, S. Süß, W. Peukert, S. Chen, D.Y.H. Pui, J. Memb. Sci. 524 (2017) 682–690.

Liquid Filtration: Effects of Chemical and Physical Factors on Filtration Performance for Micro- and Ultrafiltration Membranes

Particle Trajectory (PP Membrane)



- **Higher ionic strength enhances adhesion, reducing double layer repulsion.**






Characterization of Polydisperse Particles

Concentration Measurement Method 1

- For evaluation of membrane filter, accurate concentration measurement methods are required with proper purposes.

Nanoparticle Tracking Analysis (NTA)



- NTA can measure **particle size** and **concentration**.
- Detection range of particle size is from **20 nm to 1 μ m**.
- Linear relation** between prepared and measured concentration is obtained.

Concentration Measurement Method 2

- For evaluation of membrane filter, accurate concentration measurement methods are required with proper purposes.


Electrospray-Scanning Mobility Particle Sizer (ES-SMPS)



ES





SMPS





- ES-SMPS is based on aerosolization method.
- Detection range of particle size is from **1 nm to larger particles**.
- Linear relation** between airborne and liquid-borne particle concentration is obtained.

SEM, NTA and ES-SMPS (Monodisperse Particle)



Au 40 nm





PSL 40 nm





PSL 100 nm



PSL 150 nm




PSL 240 nm




- **Generally, NTA and ES-SMPS measure particle size well.**
- **Standard deviations obtained by ES-SMPS are more accurate (Au 40 nm and PSL 40 nm).**

SEM, NTA and ES-SMPS (Monodisperse Particle)



Au 40 nm



PSL 40 nm





ES-SMPS is more suitable for polydisperse particle characterization.





NTA and ES-SMPS (Polydisperse Particle)

Au 40 nm + PSL 100, 150, 240 nm Mixture




- **NTA** cannot distinguish four different sizes correctly due to the nature of NTA operating conditions (e.g., camera level)
- **ES-SMPS** can analyze particle sizes and concentrations as well.
 - ES-SMPS can be used for polydisperse particle filtration tests.

Monodisperse Particle Filtration



- Monodisperse particles were filtered by 0.03 μm (30 nm) rated PES* membrane (Polyethersulfone).
- Relatively low efficiency of 60 nm PSL particles were obtained.





*PES: Polyethersulfone

*D.A. Ladner, M. Steele, A. Weir, K. Hristovski, P. Westerhoff, J. Hazard. Mater. 211–212 (2012) 288–295.


Liquid Filtration: Effects of Chemical and Physical Factors on Filtration Performance for Micro- and Ultrafiltration Membranes

Polydisperse Particle Filtration 1

PSL 60 + 100 nm Mixture





- Retention efficiency of 60 nm PSL particles was significantly enhanced when challenging the membrane with 100 nm PSL particles (mixture).
- Pressure drop increases in monodisperse (superposition) and polydisperse particle cases were similar.




Polydisperse Particle Filtration 1

PSL 100 + 150 nm Mixture



- Retention efficiencies of monodisperse and polydisperse particles are similar.
- Pressure drop increase of polydisperse particle case was much larger than monodisperse particle case.

Pressure drop
increase
(polydisperse)



Thicker cake layer
Higher packing density

CONCLUSION

Modeling

- Adsorption of colloidal particles onto membrane can be predicted by three steps (**transport, interaction and force analysis**).
- Simulation methods using CFD can be applied to **different structures of membranes**.
- Depending on chemical and physical conditions, filtration performance varies significantly ($PPD < 1$).

Experiment

- NTA and ES-SMPS methods are useful for characterizing colloidal particles.
- ES-SMPS can be used for **polydisperse particle filtration** tests.
- Different mixture conditions result in different loading characteristics (efficiency and pressure drop).

Thank you

Q & A